

- Use thin sheet metal

- Larger gap will be at the bottom when installed

- Fold 90° along dotted line

- Actual size - make holes little smaller to start.

Left Side

Right Side

