Media Hub Installation

- 1. Remove ash tray, there are 2 screws on each side if you pull ash tray out. There is another under the ash tray accessible from right under the dash. Remove those 3 screws.
- 2. Disconnect wires for the ash tray light and power port and retaining clips for the wires.
- 3. Remove glove box by opening it and squeezing the sides to let the stoppers come out so whole glove box can be taken out.
- 4. The 2 copper colored squares on the sides of ash tray hole that the mounting screws thread into, reach in either the glove box hole or ash tray hole (easiest for you) using needle nose pliers or a suitable tool and squeeze the back of those threaded copper squares and they will pop out.
- 5. Now the media hub is ready to install, the top of media hub is labeled on the back. Reach through glove box hole and thread flange bolts into the media hub so that the bolts go through the hole that the copper threaded inserts used. The hole is larger than the hole so that the media hub has enough wiggle room to allow for it to fit well and it should sit snuggly in the recessed area of ash tray hole.
- 6. Once positions tighten the bolts. DO NOT OVER TIGHTEN!!

If you have any issues or questions please contact us. We use our normal warranty guidelines that can be found on our website. We will also not warranty anything created by you to mount things in the media hub if you happen to make a mistake.

